

---

# Domain Specific Architectures

## CSCE 4013/5013

David Andrews

Rm 527 JBHT

[dandrews@uark.edu](mailto:dandrews@uark.edu)

CSCE University of Arkansas



# Agenda


---

- Moore's Law
- Dennard Scaling
- Power, Energy



# Moore's Law

---



- Gordon Moore looked at several generational chips and did quick math
- "The complexity for minimum component costs has increased at a rate of roughly a factor of two per year" .....
- Interpretation - the number of components that can be fabricated in a chip is doubling every year.....




# Moore's Law

---

- Number of Transistors in an IC doubles every year (later 18 months) because:
  - The advent of metal-oxide-semiconductor (MOS) technology
  - The exponential rate of increase in die sizes, coupled with a decrease in defective densities, with the result that semiconductor manufacturers could work with larger areas without losing reduction yields
  - Finer minimum dimensions
  - What Moore called "circuit and device cleverness"



# Moore's Law Secret Sauce: Dennard Scaling



- Dennard observed that transistor dimensions could be scaled by 30% (0.7x) every technology generation, thus reducing their area by 50%.



reduce circuit delays by 30% (0.7x)

increase frequency by ~ 40% (1.4x)

voltage is reduced by 30%, reducing energy by 65% and power (at 1.4x frequency) by 50%

$$\text{Power} = CV^2f$$


If the transistor density doubles, the circuit becomes 40% faster, and power consumption (with twice the number of transistors) stays the same! What ????



# Carver Mead Explains the Physics

---


[https://www.youtube.com/watch?v=UFa\\_tk3K5oY](https://www.youtube.com/watch?v=UFa_tk3K5oY)




Computer System Design Lab

# Moore's Law Enabled the "Virtuous Cycle"

---



# Performance versus VAX-11/780 (look it up 😊)







# Power and Energy

*Power: How fast energy is transmitted*  $P = \frac{\Delta E}{\Delta \tau}$  Watt = joule/sec

*Energy: Ability to create a change* Joules = watt-second

Energy Can Be Stored, Power Cannot



[https://energyeducation.ca/encyclopedia/Energy\\_vs\\_power](https://energyeducation.ca/encyclopedia/Energy_vs_power)

<http://www.tecategroup.com/ultracapacitors-supercapacitors/ultracapacitor-FAQ.php>]]

Computer System Design Lab

# What Happened ?


---

- The dynamic (switching) power consumption of CMOS circuits is proportional to frequency ( $P = CV^2f$ ).
- Historically, the transistor power reduction afforded by Dennard scaling allowed raising clock frequencies from one generation to the next without significantly increasing overall circuit power consumption.
- breakdown of Dennard scaling resulted in the inability to increase clock frequencies. CPU manufacturers switched to multicore processors as an alternative way to improve performance.




# Power

- Intel 80386 consumed ~ 2 W
- 3.3 GHz Intel Core i7 consume 130 W
- Heat must be dissipated from 1.5 x 1.5 cm chip
- This is the limit of what can be cooled by air



# We Created a Monster That Needs Continual Feeding !!!



# Performance Via Parallelism

---

- **Cannot Clock Faster so Do More In Parallel**
  - Apply Transistors to Exploit Parallelism
  - Parallelism Exists at Different "Granularities"
  - Circuit, Data, Instruction, Procedural, Program....
- **Implicit Parallelism within a Processor**
  - Out of Order Instruction-Level parallelism (ILP)
  - Speculation
- **From the Application Program**
  - Data-level parallelism (DLP)
  - Thread-level parallelism (TLP)
  - Domain Specific Acceleration (DSA)



# Further Fun...

---



Gordon Moore & Carver Mead: *Moore's Law 40<sup>th</sup> Anniversary with Gordon Moore*

<https://www.youtube.com/watch?v=MH6jUSjpr-Q>

